

SOLENOID TEST: (Engine off)				
Solenoid	TranX Setting	Output Channel	AMPS Cold-Hot	Resistance Cold-Hot
Solenoid 1	Gear 1	1	0.4 - 0.3	35 - 45 Ω
Lock-up Solenoid	Gear 5	5	0.4 - 0.3	35 - 45 Ω

CAUTION:

Always come to a COMPLETE STOP & TURN ENGINE OFF before changing test modes

SHIFT/MONITOR TEST		
GEAR	Solenoid 1	L.U. Solenoid (FS 2)
1st	OFF	OFF
2nd	OFF	OFF
3rd	OFF	ON/OFF
4th	ON	ON/OFF

Notes:

- ◆ Transmission must be in **3rd or 4th** gear for **Lock Up**.
- ◆ Polarity = Common **Positive**

